



AF03GT

Program for weighbridges

CALIBRATION METHOD - v7

ENGLISH



For 3590 series touch screen indicators

Index


Calibration of a channel connected analogue weighbridge	4
Analogue calibration with equalisation	8
Setting and calibration of digital cell weighbridges	12
Calibration of a WWS wireless weighing system	16
Calibration of a dual digital weighbridge system	20
Calibration of a dual scale system consisting of wireless WWS platforms	26




Calibration of a channel connected analogue weighbridge

PREMISE

CASE 1: An indicator connected to a weighbridge.




CASE 2: An indicator connected to a scale composed of several weighbridges in series (up to 48 1000 Ohm cells).




Procedure:

A. With switched-off indicator and power supply unplugged, connect the weighbridge to the indicator.




B. Turn on the indicator, enter the setup menu and check that the signal coming from the weighbridge is stable and increases with weight increase.

1.



2.




3.

SCALE 1				W1
kg 15000				A d=74
Channel	ADC	min	MAX	
1	344673	308333	308333	


Esc ADC-mV

C. Select the number of weighbridges and each weighbridge load cell type.

1.




2.




D. Set scale metric parameters (capacity / division, etc.)


1.



2.




3.




Example of dual scale weighbridge configuration: Number of decimals = 0; Unit of measure = kg; Range number = 2; Range 1 division = 10; Capacity / Range 1 = 30000; Range 2 division = 20; Capacity / Range 2 = 60000.

E. Perform calibration.


1.




2.




3.




4.




5.




6.




7.




8.




9. Load the weighbridge and distribute the mass evenly.




10.



11.





12.



F. Repeat the procedure from step **C** for calibration of the second weighbridge (if present).

G. Perform backup



It is possible to enter a protection password to restore the stored parameters.




Saving has completed correctly only if the asterisk is present:

Backup of the configuration (*)

H. Receive calibration with Dinitools.


I. Exit setup and save.




Analogue calibration with equalisation

PREMISE

CASE 1: The weighbridge load cells are connected to the 4 indicator channels.



CASE 2: Scale composed of various weighbridges in sequence, each connected to a channel of the indicator.



Each weighbridge shall be individually equalised via junction box.

Procedure:

- A.** With switched-off indicator and power supply unplugged, connect the scale to the indicator.
- B.** Turn on the terminal, enter the setup menu and check that the signal coming from the scale is stable and increases with weight increase.

1.

Technical set-up

...

...

...

Diagnostic

...

...

Esc

↑

↓

2.

Diagnostics

...

...

...

Weight test

...

...

Esc

↑

↓

3.

SCALE 1

kg

15000

W1

A

F=7

d=24

Channel

ADC

min

MAX

1

344673

308333



308333

Esc

ADC-mV






C. Select the number of scales and load cell type.


- 
- 

= 1
= Analogue
= 2 ... 4


D. Set scale metric parameters (capacity/division) etc.

- 
- 
- 


E. Perform the guided equalisation procedure.



For CASE 1: equalisation aims to optimise the angles of the scale.




For CASE 2: equalisation aims to make each weighbridge the same, in order for the weight measured on each individual one to be the same.




F.


1.




2.




3.




4.




5.




6.




7.




8.




9. Load the weighbridge and distribute the mass evenly.




10.



10.




11.




Perform the procedure for each channel.

G. Perform backup


1.



2.



3.



It is possible to enter a protection password to restore the stored parameters.





Saving has completed correctly only if the asterisk is present:

Backup of the configuration (*)


H. Receive calibration with Dinitools.

I. Exit setup and save.




Setting and calibration of digital cell weighbridges

PREMISE




CASE 2:




Procedure:

- A.** With switched-off indicator and power supply unplugged, connect the scale to the weighing terminal 3590.



- B.** Select the number of scales and load cell type.




= 1
= RCPTD, RCD, SP/CS, CB50X-DL, RC3D
RL5426/RL5416, C16i, ZSFD, DGX, WWS
= 1 - 16


- C.** Set digital cell serial number.

Premise


Number the load cells for easier identification during maintenance, for example:



1.




2.



= Enter for each load cell its serial number, displayed on the casing of the cell.

D. Perform the load cell automatic numbering procedure:

1.



= The indicator assigns to each load cell its number, which will identify it in each programming or diagnostics menu.


If the operation does not succeed, check connection between cells and indicator.




If the operation succeeds, set the dip switch to "ON" to enable termination resistor.

E. Set scale metric parameters (capacity/division) etc.


1.



2.





3.




F. Perform equalisation following the indicator's guided procedure.


1.



Example of a 4 cell weighbridge: equalisation aims to optimise each cell of the scale.




Example of an 8 cell weighbridge: equalisation aims to optimise each cell of the scale




G. Perform calibration.


1.




2.




3.




4.




5.




6.




7.




8.




9. Load the weighbridge and distribute the mass evenly.




10.



11.




12.




Perform the procedure for each scale.

H. Perform backup


1.



2.



3.



It is possible to enter a protection password to restore the stored parameters.





Saving has completed correctly only if the asterisk is present:

Backup of the configuration (*)

J. Receive calibration with Dinitools.


K. Exit setup and save.



Calibration of a WWS wireless weighing system


PREMISE

System diagram:




Procedure :

- A.** Calibrate and set metric parameters of each WWS platform. Check that each platform is configured on the same radio channel (channel "0")
- B.** With indicator switched-off and disconnected from the electrical grid, connect the radio module to the AUX port.




C. Set the instrument's radio channel


1.




2.




3.




4.



5.




6.




D. Select the number of WWS which make up the system.

1.



2.




= 1

= WWS

= Corresponds to the number of WWS platforms which make up the system, set from 1 - 16.


E. Establish communication between indicator and WWS platform.

1.



= Acquires metric parameters from the WWS and modifies them on the indicator.
If the operation does not succeed, check connection with the platforms.

2. Set the gravity value of the area of use.





This operation overwrites the data in the memory.



If WWS platforms are approved for use in relation with third parties:

- total system capacity must be equal to the sum of each individual WWS platform's capacity.
- system division must be equal to the sum of each individual WWS platform's division rounded up to the highest one.
- set these parameters to be able to approve the system.

E.g.: in a system consisting of 8 WWS platforms with "Max.=15,000kg" and "e=5kg", maximum capacity will be "Max.=120,000kg" and the division "e=50kg".

If the platforms are not approved:


- total system capacity must be equal to the sum of each individual WWS platform's capacity.
- system division equals division of the single WWS platform.

E.g.: in a system consisting of 8 WWS platforms with "Max.=15,000kg" and "e=5kg", maximum capacity will be "Max.=120,000kg" and the division "e=5kg".


The system's total capacity and division can be modified to create specific internal use systems (see step **F**).

F. Set indicator metric parameters (if required).


1.



2.




3.




G. Perform backup


1.



2.



3.



i

It is possible to enter a protection password to restore the stored parameters.



i

Saving has completed correctly only if the asterisk is present

Backup of the configuration (*)

H. Receive calibration with Dinitools.


I. Exit setup and save.



Calibration of a dual digital weighbridge system

PREMISE

System diagram:



i It is possible to install weighing systems with more than one weighbridge based on the number of cells of each (Max. 16 digital cells, max. 8 CCI AD cells).


With this configuration the weight of each platform is displayed separately.

GROSS		
kg		
A	B	
kg	kg	
PRESET	NOTES	
CUSTOMER	SUPPLIER	
MATERIAL		
VEHICLE	FREE PLATE	
→0←		→0←
1. WEIGH	2. WEIGH	PRINT
		>>


Weight “A”, Weight “B”
or Sum “A” + “B”
(enabling “A+B” function).
See page 23

Procedure:

- A.** With switched-off indicator and power supply unplugged, connect the scale to the weighing terminal 3590.



- B.** Select the number of scales and load cell type




Total of selectable cells in the dual scale configuration is "16".

C. Set digital cell serial number.

Premise

Number the load cells for easier identification during maintenance, for example:



1.

Scale selection	
...	↑
...	
Serial number configuration	↓
...	
...	
...	
...	
Esc	

2.

Serial number configuration	
...	↑
...	
Cell n	↓
...	
...	
...	
Address assignment	↓
Esc	

= Enter for each load cell its serial number, displayed on the casing of the cell.

D. Perform the load cell automatic numbering procedure:

1.

Serial number configuration	
...	↑
...	
Cell n	
...	
...	
...	
Address assignment	↓
Esc	

= The indicator assigns to each load cell its number, which will identify it in each programming or diagnostics menu

If the operation does not succeed, check connection between cells and indicator.



If the operation does not succeed, set the dip switch to "ON" to enable termination resistor.

E. Set scale metric parameters (capacity/division) etc.

1.

Calibration	
...	↑
...	
Scale 1	↓
Scale 2	
...	
...	
...	
Esc	

2.

Scale configuration	
...	↑
...	
Parameters	↓
...	
...	
...	
...	
...	
Esc	


3.

Parameters	
Number of decimals	↑
Unit of measure	
Range number	
Range 1 division	
Capacity / Range 1	↓
Range 2 division	
...	
...	
...	
Esc	


Example of dual scale weighbridge configuration: Number of decimals = 0; Unit of measure = kg; Range number = 2; Range 1 division = 10; Capacity / Range 1 = 30000; Range 2 division = 20; Capacity / Range 2 = 60000.

F. Perform equalisation following the indicator's guided procedure.


1.



For **CASE 1**: equalisation aims to optimise the angles of the scale.




For **CASE 2**: equalisation aims to make each weighbridge the same, in order for the weight measured on each individual one to be the same.




G. Perform calibration.


1.




2.




3.




4.




5.




6.




7.




8.




9. Load the weighbridge and distribute the mass evenly.




10.



11.



12.




i

Perform the procedure for each scale.


How to display the sum of "A"+"B"

With this configuration it is possible to display simultaneously the weights of the two platforms and their sum.


1.



2.




3.




H. Perform backup


1.



2.



3.



It is possible to enter a protection password to restore the stored parameters.





Saving has completed correctly only if the asterisk is present:

Backup of the configuration (*)

I. Receive calibration with Dinitools.


J. Exit setup and save.



Calibration of a dual scale system consisting of wireless WWS platforms

PREMISE

System diagram:




With this configuration the weight of each platform is displayed separately.

GROSS	
A	B
kg	kg
PRESET	NOTES
CUSTOMER	SUPPLIER
MATERIAL	
VEHICLE	FREE PLATE
→0←	→0←
1. WEIGH	2. WEIGH
PRINT	>>


Weight “A”, Weight “B” or Sum “A” + “B” (enabling “A+B” function).
See page 23

Procedure:


- A.** Calibrate and set metric parameters of each WWS platform. Check that each platform is configured on the same radio channel (channel "0")
- B.** With indicator switched-off and disconnected from the electrical grid, connect the radio module to the AUX port.



- C.** Separate and identify the platforms for weighing the traction unit from those for weighing the trailer. This division shall be followed for each weighing procedure.



Trailer WWS group



Traction unit WWS group

i

Traction unit WWS group = Scale 1

Trailer WWS group = Scale 2

- D.** Select the number of scales and number of WWS platforms for each scale.

1.

2.

= 2 ("scale" means a group of WWS)

= WWS

= 1 - 16 Enter the number of cells of the traction unit group and of the trailer group

= 1 - 16




The total of selectable WWS platforms in the dual scale configuration is "16".




E. Establish communication between indicator and WWS platform.

1.



= Acquires metric parameters from the WWS and modifies them on the indicator.
If the operation does not succeed, check connection with the platforms.

2. Set the gravity value of the area of use.



i

This operation overwrites the data in the memory.

i

If WWS platforms are approved for use in relation with third parties:

- total system capacity must be equal to the sum of each individual WWS platform's capacity.
- system division must be equal to the sum of each individual WWS platform's division rounded up to the highest one.
- set these parameters to be able to approve the system.

E.g.: in a system consisting of 8 WWS platforms with "Max.=15,000kg" and "e=5kg", maximum capacity will be "Max.=120,000kg" and the division "e=50kg".

If the platforms are not approved:


- total system capacity must be equal to the sum of each individual WWS platform's capacity.
- system division equals division of the single WWS platform.

E.g.: in a system consisting of 8 WWS platforms with "Max.=15,000kg" and "e=5kg", maximum capacity will be "Max.=120,000kg" and the division "e=5kg".


The system's total capacity and division can be modified to create specific internal use systems (see step **F**).

F. Set indicator metric parameters (if required).


1.



2.




3.




How to display the sum of “A”+”B”

With this configuration it is possible to display simultaneously the weights of the two platforms and their sum.



G. Perform backup




It is possible to enter a protection password to restore the stored parameters.

Saving has completed correctly only if the asterisk is present

Backup of the configuration (*)

H. Receive calibration with Dinitools.

I. Exit setup and save.



Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

This publication, or portions thereof, may not be duplicated without written permission from the Manufacturer. All information herein is based on the data available at the time of publication. The Manufacturer reserves the right to make changes to its products at any time without notice and without incurring any penalty. We therefore recommend that you always check for any updates.

The individual in charge of operating the scale must ensure that all safety regulations in force in the country of use are applied, ensuring that the appliance is used in accordance with the purpose it is intended for and to avoid any danger for the user.

The Manufacturer declines any liability arising from any weighing operation errors.



**HEAD OFFICE**

Via Della Fisica, 20
41042 Spezzano di Fiorano, Modena - Italy
Tel. +39 0536 843418 - Fax +39 0536 843521

SERVICE ASSISTANCE

Via Dell'Elettronica, 15
41042 Spezzano di Fiorano, Modena - Italy
Tel. +39 0536 921784 - Fax +39 0536 926654

www.diniargeo.com

Authorised service centre stamp

